Work Ordo July-04-13 2:30	er ID 10393 0:48 PM	34		*103	3934*						Page 1
Item ID: Revision ID:	646.9602 LOWER CUTTER	ASSV HIGH		Accept	*N900	040	100	)* s	etup Start Stop	171	S1*
Item Name: Start Date: Required Date: Reference:	7/04/13 St	eart Qty: 1.00	*1* *1*		Cust Item I Customer:	ID:			·	"IN	S2*
Approvals:	Process Plan: _ QC:		Date:			ate:		R	un Start Stop	"IVI	R1* R2*
Sequence ID/ Work Center II		peration escription		Set Up/ Run Hours	Tool ID	Tool #	Plan Code	Accept Qty	Reject Qty	Reject Number	Insp. Stamp
Draw Nbr	Revisio	n Nbr									
646.9600	N/C										
110	Pic	k Kit		0.00	(						
*110* Packaging Packaging		Memo		0.00					•		i
120				0.00	(				. 6	7	
*120* Small Fab				0.00			(			5130	7.04
Small Fab		Memo Assemble a	s per dwg and apply loci	tite 598 on all faying surface	es per note 2.						
** **		A/R RTV I	LOCTITE 598: 1/125	306							
્રા <sub>30</sub> *130	QO	C5- Inspect part comp	eleteness to step on W/O	0.00				2			04 25 12.00
QC Quality Control		Memo		0.00							· • • • • • • • • • • • • • • • • • • •

Work Orde		103934		*103	3934*				- 11- May			Page 2
Item ID: Revision ID:	646.960	2		Accept	*N900	<b>040</b>	100	)*	Setup	Start	*N	S1*
Item Name:	LOWER	CUTTER ASSY HIGH								Stop	*N	S2*
Start Date:	7/04/13	Start Qty: 1.00	*1*		Cust Item I	D:					_	
Required Date:	7/04/13	<b>Req'd Qty:</b> 1.00	*1*		<b>Customer:</b>							
Reference:							=	,	D	Staut		
Approvals:	Proces	s Plan:	Date:	Tooling:	Da	ate:		j	Run	Start	*N	R1*
	QC:_		Date:	SPC (Y/N):	Da	ate:				Stop	*N	R2*
Sequence ID/ Work Center I	D	Operation Description		Set Up/ Run Hours	Tool ID	Tool #	Plan Code	Accept Qty	Re Qt	-	Reject Number	Insp. Stamp
41 <b>40</b>		Identify as per dwg & St	ock Location:	0.00				_			. 1	
*140* Packaging Packaging		Memo ***IDENTI	FY AS PER IAW MPP-1	0.00 20***				2 <u>y</u>	<u>!</u>	Y	.Ll. ,	13-07-0
											,	١.
150		QC21- Final Inspection	- Work Order Release	0.00					12	11	سيرا	1
*150* * QC				0.00					-   /		12	47)
Quality Control		Memo		0.00							۸ پ	Wr _
V .							•					~ N
												13.7-31
												•

Page 1

Work Order ID:

103934

Parent Item:

646.9602

Parent Item Name:

LOWER CUTTER ASSY HIGH

**Start Date:** 7/04/13

Required Date: 7/04/13

Start Qty: 1.00

Required Qty: 1.00

Comments:

IPP REV:A 12.08.13 NEW ISSUE DD VERF:JFS

Component Item ID/ Item Name	Replacement Item ID	Mfg/ Purch	Bin Item	Primary Location	Last Location	Route Seq ID	Unit of Measure	Qty on Hand	Qty per Kit	Total Qty	Qty Issued	Date Issued	Status
646.9701		Manufactured	No			110	Each	49.0000	1	1			
Cutter Sub Assembly				1					(** <del></del> .=	**************************************			<del></del>
				<b>Location</b>		Loc Qty	<u>Lo</u>	c Code		€.	$\cap$	_	
•				MF		49		Ô Â				1307	my.
				897	9 <b>)</b>	9		) ·					
				912		26		11 8					
				917		12				<del></del>			
(4( 0012			2.7	925	58	2							
646.9812	CTOD	Manufactured	No			110	Each	20.0000	1	1			
LOWER CUTTER DEFLE	ECTOR								· · · · · · · · · · · · · · · · · · ·				
•				<b>Location</b>	<i>t</i>	Loc Qty	<u>Lo</u>	c Code		A. A.		1307	04
				ST438	_	20						1 /2 0	,
3				C 898		10							
				912	76	10							
MS21042L08		Purchased	No			110	Each	3,593.0000	3	3	Ŵ	120	M3
Nut								٠.	· · · · · · · · · · · · · · · · · · ·			<u> </u>	<i></i>
				<b>Location</b>		Loc Oty	<u>Lo</u>	c Code	<b>\</b>				
				ST315		1593		3					
•				122		3							
				122		9					(A)	1300	ass.
				122		500						. 120	-7
				123	9017	1081			<del>.</del>	<del></del>			
				ST505	445	2000			<del></del>				
•				125	445	2000							

## **Picklist Print**

July-04-13 2:30:47 PM

Page 2

Work Order ID: Parent Item: Parent Item Name:		103934 646.9602 LOWER CUTTER ASSY HIGH		·			Start Date: 7/04/13 Start Qty: 1.00			Required Date: 7/04/13 Required Qty: 1.00		
	MS27039-08-19 Screw	Purchased	No		110	Each	2,236.0000	3	3			
				Location	Loc Qty		Loc Code			4	$\bigcirc$	
				ST307	89					4	13000	
				123525	89						13000	
				ST309	947							
				(12 <i>8</i> 654)	947							
				st510	1200							
				124309`	1200							
	NAS1149FN832P	Purchased	No		110	Each	16,128.000	6	6		13.07.04	
	Washer							· * 8 8 9 = 2				
	<b>7</b>			<b>Location</b>	Loc Oty		Loc Code					
, ,				ST294	6128						4.	
5				123592	400							
في ج	á -			123900	5728				<del></del>			
. "				ST510a	10000							
į				125268	10000			<del></del>	<del></del>			

							·										-
			ENO	3INE	ERI	NG CI	HANGE	NOT				0274	3		SHEE	Ti	
4	ΔF	PTCAL	DW	G N	Ο,	646.9	9600	REVIN	1/C	PREPARED BY	S.H	IUFF	DATE	: 01/	07/10	EFFE(	CT ON DW : 🛛 UNINC
1 '	٠.	STRIES, INC.	DW	G T	ITL	- 1 - 1			CL	ITTER	AS:	SY	// .				
		5111220, 2710.	APPRE	IVED B	YI ENGR	7300	and a	MFC	i densit	Jones		QC	MINTE	7 /2	EFFi	NEXT OF	RDER
l A	ANSA -ADI -RE\	CTION CODES (TC): C-CREATE /ISE D-DELETE	RE#	ADD/	l: RE≀	VISED :	SCREW	LENGTH	1	1 57							
			•														
***************************************																	
3	R	601.3157	3	3	3	SCREW				#		M	IS27039-081	8	······································		
			.9603	.9602	.9601												
F/N	TC	PART NUMBER		QTY		DESCRI	IPTION						MATERIA				
DO	CUMI	ENTS EFFECTED:		MDL	□ I	ISTALL	INSTRUC	⊠ ICA	4 🗆 F	MS 🛭 E		IANGE C MAJOR	ATEGORY     XI MINOR		REVIEW YES	REQUIRE NO	ED

.

